

## Instruction Manual

# AromaVase<sup>™</sup>

by AromaHouse<sup>™</sup>



ULTRASONIC  
AROMATHERAPY  
NEBULIZER  
Perfect for essential  
oils and fragrances



INNOVATIVE  
CANADIAN DESIGN  
AromaHouse is a registered  
trademark of Hubmar.

[www.hubmar.com](http://www.hubmar.com)

## TECHNICAL SPECIFICATIONS

<b>Dimensions:</b>	113mm (w) x 155mm (h)
<b>Weight:</b>	Approx. 640g
<b>Power:</b>	Input/Output AC100-240V 50/60Hz DC 24V 650mA
<b>Time mode:</b>	<b>Continuous spray / Intermittent spray (30s ON / 30s OFF)</b>
<b>Tank capacity:</b>	100ml
<b>Accessories:</b>	Ultrasonic unit Power supply Measuring cup
<b>Operation frequency:</b>	2.4MHz

### ATTENTION:

Before storing the unit, empty water tank and towel dry.

The unit will automatically shut off when water level is too low.

The unit will not work without water.

Due to water type, humidity, temperature and air currents, the amount and intensity of mist produced will vary during normal use.

Cleaning the unit every time you change oils is recommended as oils can, over time, build up on ceramic parts.

## OPERATING INSTRUCTIONS

1. Remove the upper cover.
2. Connect power supply to base of unit via cable guide.
3. Use the measuring cup (included) to add 100ml of water to the tank. The unit will not work without water. Do not exceed the maximum fill level.
4. Add 3 to 5 drops of your favorite essential oil to the water, replace cover (cover must be in place before turning the unit on).
5. With dry hands, plug the adaptor into a standard household outlet. Unit will "Beep" twice and remain in standby mode.

**6. Press the mist (right) button once for continuous mist pattern. Press twice for intermittent mist pattern (30s ON / 30s OFF). Press a third time (or press and hold at any time) to turn misting off.**

**7. Press the light (left) button to turn LED lights ON. Lights turn on in multi-color mode. For fixed color light mode, press button when desired color appears. Press again to return to multi-color mode. Press and hold at any time to turn lights off.**

## DISCLAIMER

- Follow the operating instructions.
- Should a problem arise, unplug the unit. Do not attempt to open the unit. The unit must be serviced by a qualified technician. Return to the store or retailer where you bought the unit.
- Do not damage, twist or pierce the power supply cord. Do not let the power supply cord come in contact with high temperatures or place heavy objects on the cord.
- If the power cord gets damaged, stop using it.
- If there are any abnormal odors, noises or generation, unplug the unit from the wall socket and discontinue use.
- Do not use the unit in a wet environment (i.e. bathroom, greenhouse, etc.).
- To keep the unit in good working order, drain water after each use and clean with a soft cotton cloth.
- If essential oils spill, clean immediately with a dish cloth to avoid staining.
- Fill unit using measuring cup provided, never directly from tap.
- Avoid misting directly on furniture, clothes or walls.
- Avoid placing unit in direct sunlight, extreme high or low temperatures, near fans or air conditioners.
- Do not place unit on appliances (i.e. TV, audio equipment).
- Do not cover the unit.
- After prolonged use the unit should be turned off for at least an hour to avoid damaging the ultrasonic plate.

## TROUBLESHOOTING

### Unit turned ON, but turns OFF within 1 second:

- Make sure there is enough water in the tank to run the unit.
- Check that the unit is properly connected to the power supply.

### NO MIST OR ABNORMAL MIST:

- Make sure there is enough water in the tank to run the unit, but water does not exceed max water level.
- Check that the ultrasonic plate is clean, if not, clean it.
- Check that the bottom of the unit is free of debris, if not, clean it.

### UNIT IS LEAKING:

- Make sure the cover is in place.
- Make sure there is no condensation on the outside of the unit caused by low temperature or high humidity.

## ACCIDENTAL LEAKAGE

If the unit is knocked over during use:

1. Unplug the unit and remove the cover.
2. Pour any remaining water out of the tank.
3. Gently shake the unit to drain any water from inside the mechanism.
4. Allow the unit to air dry for at least 24 hours.

- Use tap or purified water only.
- Keep the unit on a flat and secure surface at all times.
- If moving the unit, ensure you unplug the unit from the power supply.
- Turn the power off when not in use.
- Do not operate the unit with wet hands.
- Do not immerse the unit in water.
- **KEEP AWAY FROM CHILDREN AND PETS.**

## MAINTENANCE

After using the unit 5 to 6 times or for 3-5 days, clean the unit as follows:

1. Unplug the unit and remove the cover.
2. Pour any remaining water out from the DRAIN SIDE of the water tank.
3. Put 1 tablespoon of lemon or lime juice into the tank, add 100ml of warm water, let sit, drain and wipe with clean cloth.
4. If there is any dirt in the air outlet remove the container cover and clean it.
5. Never use other acids, enzymes or detergents, as they may cause the unit to malfunction.

### ATTENTION:

**Do not use neutral detergent.  
Do not wash in a dishwasher.**